


1946 S. Myrtle Ave, Suite B

Monrovia, CA 91016

+1-626-294-1777 Phone

customerservice@grandstands.com

www.grandstands.com





ACE-15 MONITOR ARM

Please Note!

Please pay careful attention to all instructions for mounting and adjusting the 5 friction joints:

Height Control


Tilt Control

Rear Pivot


Center Pivot


Front Pivot

The ACE monitor arm can support monitors, tablets, writing trays, virtually anything that needs 3D adjustability across a wide range of space.



Step 8: Swivel Friction Adjustment For Horizontal Rotation





Specifications

Maximum Extension From Post: 23.31"

Depth from Post (Closed): 0"


Tilt adjustment: ±15°


Display Pan Swing - Side to Side: 180"

VESA Compatibility: 75x75mm/100x100mm


Height Range : 15"

Weight Capacity : ACE-15 0 - 15 LB





Step 5: Tilt Friction Adjustment



Step 6: Monitor Weight Friction Adjustment

The ACE monitor arm uses a novel one-way friction device to hold the weight of the monitor(s). To set the ideal amount of friction, mount your monitor to arm and raise the arm to horizontal (parallel to desk). If the monitor does not hold height, increase friction by turning bolt clockwise until arm holds monitor when horizontal. Do not over-tighten bolt; too much friction will result in an unnecessary amount of force required to lower the monitor.

TO PREVENT FAILURE OF ARM, DO NOT TURN FRICTION ADJUSTMENT BOLT MORE THAN ONE (1) FULL TURNS COUNTERCLOCKWISE

